



...the choice matters

**Surewalk MD3000**  
**Diamond Fitting Instructions**

[www.matsdirect.co.uk](http://www.matsdirect.co.uk)

The layout for the modules is as follows:

1. Find the centre line of the matwell from left to right. The centre line should run through the centre of the module.
2. Modules are laid in landscape format, the first module should be placed in the centre at the furthest point from the door threshold in the matwell.
3. Place each module to the left and right of this module leaving NO gaps until the edge is reached.
4. Lift the edge of the module and coat the matwell frame with chalk.
5. Gently lay the module over the matwell edge to coat the module with the chalk and cut on the inside of the chalk line using a sharp, fixed blade knife.
6. Repeat the operations 3 - 5 placing modules from the first line back to the door threshold of the matwell until the matwell is fully covered with the modules and then trim the final line of modules to make the installation complete.

**Concourse modules are butt-fitted and require no clearance as they are manufactured to be stable in a normal temperature changing environment.**

**If in doubt, please call +44 (0) 161 797 6785 and ask for the Technical department for further help and information.**

**MatsDirect UK Ltd**  
Unit 2 Bolholt Industrial Park  
Walshaw Road  
Bury, Lancashire  
BL8 1PL UK

**For all enquiries:**

**Tel:** 0044 (0)161-797-6785  
**Fax:** 0044 (0)161-797-6349  
**E-mail:** [sales@matsdirect.co.uk](mailto:sales@matsdirect.co.uk)